



Kurzanweisung ^[DE]

Richtige Temperatureinstellung für DEPILEVE und SALON CLASSICS Wachskartuschen 100 ml

- 1) Nehmen Sie die Schutzkappe von der Heizkammer ab, entfernen Sie das Etikett von der Wachskartusche auf dem Roll-On Aufsatz und setzen Sie die Wachskartusche in die Heizkammer ein. Die Schutzkappe zum Aufheizen wieder aufsetzen.
- 2) Drücken Sie die Ein/Aus-Taste um das Gerät einzuschalten.
- 3) Zum Aufschmelzen der Wachskartusche für ca. 20 Minuten auf 120°C einstellen, bis das Wachs vollständig aufgeschmolzen ist.
- 4) **Einstellung Arbeitstemperatur:** Für die meisten Wachskartuschen bzw. DEPILEVE und SALON CLASSICS Wachskartuschen 100 ml sollte die Temperatur zwischen 75°C und 95°C eingestellt werden, je nach dem wie flüssig das Wachs sein soll.

Nach dem Einstellen der gewünschten Temperatur springt das Display zunächst wieder auf die aktuelle Ist-Temperatur zurück. Anschließend steigt oder fällt die Temperatur Schritt für Schritt bis zur eingestellten Zieltemperatur.

- 5) Um zu testen ob das Wachs flüssig genug ist, versuchen Sie die Kartusche über einen Vliesstreifen mehrmals abzurollen.
- 6) Testen Sie die Temperatur des Waxes immer zuerst an einer unempfindlichen Hautfläche aus. Wenn es nicht zu heiß ist, können Sie mit dem Wachsen beginnen.
- 7) Tragen Sie das Wachs gegen die Haarwuchsrichtung auf. Legen Sie einen Vliesstreifen auf und drücken Sie den Streifen mit der Handflächen an. Ziehen Sie den Vliesstreifen gegen die Haarwuchsrichtung ab. Gegendrücken der Haut nicht vergessen.
- 8) Eventuelle Wachsrückstände mit einem Oil Cleanser oder Milk Cleanser entfernen.

Quick Guide [EN]

Correct temperature setting for DEPILEVE and SALON CLASSICS 100 ml wax cartridges

- 1) Remove the protective cap from the heating chamber, take off the label from the wax cartridge on the roll-on head, and place the wax cartridge into the heating chamber. Put the protective cap back on for heating.
- 2) Press the On/Off button to switch the device on.
- 3) To melt the wax cartridge, set to 120°C for approx. 20 minutes, until the wax has fully melted.

4) Working temperature setting:

For most wax cartridges, including DEPILEVE and SALON CLASSICS 100 ml wax cartridges, set the temperature between 75°C and 95°C, depending on how fluid you want the wax to be.

After setting the desired temperature, the display first returns to the current (actual) temperature. The temperature then rises or falls step by step until it reaches the set target temperature.

- 5) To check whether the wax is fluid enough, try rolling the cartridge over a non-woven strip several times.
- 6) Always test the wax temperature first on a less sensitive area of skin. If it isn't too hot, you can begin waxing.
- 7) Apply the wax against the direction of hair growth. Place a non-woven strip on top and press it down firmly with the palm of your hand. Pull the strip off against the direction of hair growth. Don't forget to hold the skin taut.
- 8) Remove any remaining wax residue with an Oil Cleanser or Milk Cleanser.

